LCC: Entering Ramp Values
August 1, 2000

Summary
This note describes how to enter ramp values manually into the LCC.

Auto Calc
When creating a new ramp with the LCC, the LCC will by default automatically recalculate shutter values for any entered fps values. Sometimes this is not desirable, for instance if a fade-down effect is wanted. For this purpose, the automatic shutter calculation (Auto Calc) can be turned off. When “Auto Calc Shutter” is off, any shutter value can be entered and the LCC will leave it alone.

1. Choose “New” from the “Programs” menu.
2. The “Edit Program” window will appear. Locate the “Auto Calc Shutter” checkbox in the lower right corner.
3. Make sure the “Auto Calc Shutter” checkbox is NOT checked.



For more information on this issue, please contact your local ARRI representative.